




FJD ISOBUS

User Manual



Copyright Notice:

FJDynamics reserves the copyright for this manual and all content herein. No part of this manual may be reproduced, extracted, reused, and/or reprinted in any form or by any means without the prior written permission of FJDynamics.

This manual is subject to change without notice.

Revisions:

Version	Software	Date	Description
2.0	V25.10x.1	2025.08.01	Overall optimization of ISOBUS-related features

Read Before Use:

	Operate in strict accordance with this software user manual. If you have any questions during use, contact the service personnel.
---	---

Disclaimer:

- The purchased products, services, and features are stipulated by the contract. All or part of the products, services, and features described in this manual may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, all the content in this manual is provided "AS IS" without warranties of any kind, express or implied.
- The content of this manual is subject to change due to product upgrades and other reasons. FJDynamics reserves the right to modify the content of this manual without notice.
- This manual only provides guidance for use of this product. Every effort has been made in the preparation of this manual to ensure accuracy of the content, but no information in this manual constitutes a warranty of any kind, express or implied.

Safety Instructions

Before using this product, ensure that you have read and understood all the operation instructions and precautions in the *FJDynamics Auto Steer System Software User Manual* and this manual.

Operator

1. People under eighteen or not meeting the age requirement of local laws and regulations are not allowed to operate this product.
2. Do not drive under the influence of medicines, alcohol, and drugs.
3. Do not drive when feeling tired.
4. Operators must hold the driving licenses as required by local laws and regulations.

Operating Environment

1. Drive in an open field far from the crowd and ensure that there are no irrelevant personnel or vehicles in the operation area.
2. Keep away from people, animals, obstacles, electric wires, tall buildings, airports, signal towers and other obstacles to protect operations from signal interference.
3. Do not operate the machine in extreme weather such as heavy rain, thick fog, snow, lightning, or strong wind.
4. Ensure that there are no people or obstacles around the machine's path during testing, calibration, adjustment, or automatic turning to prevent personal injuries or property damage.

Operation

1. Do not get on or off the vehicle during operation.
2. Stay in the vehicle and monitor the whole operation process to ensure timely intervention.
3. Drive the vehicle equipped with the system manually on public roads or in public areas.

Inspection

1. Ensure that the vehicle contains sufficient fuel and spray material.
2. Ensure that the parameters are calibrated in the control terminal before autosteering.
3. Ensure that the antennas and attitude sensor are installed properly. In case of any displacement, perform calibration before use.
4. Ensure that the cables are intact. Stop the operation and replace the cables in case of damage.

Others

1. Disassembling the product housing without authorization may invalidate the warranty.
2. Damage caused by force majeure events, such as lightning strikes, overvoltage, and collision, is not covered by the warranty.
3. Connect the devices strictly in accordance with this manual. When connecting cables such as data cables, hold the end of the plug and gently plug or unplug it. Do not pull the plug by force or twist it, which may break the pins.
4. Follow the power supply requirements for this product (system). The supply voltage for the control terminal and the electric steering wheel is 9 V–36 V.

Preface

Use of Manual

This manual describes how to use FJDynamics ISOBUS function through simple and clear operation processes, so that users can learn to perform each operation easily, quickly, and accurately.

Technical Support

Starting from the date of purchase, users will be provided with the technical support and upgrade services from FJDynamics.

Contact FJDynamics by any of the following methods:

Tel: +1 833-330-6660 (US)

Tel: +496 931 090 130 (Europe)

Official website: <https://www.fjdynamics.com>

Table of contents

1. Product Introduction	7
1.1. Overview	7
1.2. Main Components	8
1.2.1. ISOBUS Wiring Harness	8
1.2.2. ISOBUS Ready Wiring Harness	8
1.3. Hardware Installation	10
1.3.1. FJDynamics Auto Steer Kit	10
1.3.2. ISOBUS Wiring Harness	10
1.3.3. ISOBUS Ready Wiring Harness	10
2. Software Operation Instructions	12
2.1. Overview of Operation Processes	12
2.2. Setting the Auto Steer System	12
2.3. Function Enabling	12
2.3.1. Enable VT	13
2.3.2. Activate and Enable TC-SC	13
2.3.3. Activate and Enable TC-GEO	15
2.3.4. Activate and Enable AUX-N	15
2.4. Implement Connection	15
2.5. Preparation	16
2.5.1. Implement Setup	16
2.5.2. TC Object Pool Update	21
2.5.3. Material Setup	21
2.5.4. Import Task Files	22
2.5.5. Task Setup	22
2.5.6. Prescription Setup	23
2.5.7. Check Record Mode	24
2.5.8. Speed source setup	25
2.6. Start Operation	26
2.6.1. Main Screen Elements	26
2.6.2. Start/Pause Task	28
2.6.3. VT Operation	28
2.6.4. TC Operation	28
2.6.5. Auxiliary control (AUX-N)	33
2.7. ISOBUS Module	34
2.7.1. Implement Info	35
2.7.2. Statistics	35
2.7.3. Settings	36
3. Hardware Specifications	40
3.1. FJDynamics Auto Steer Kit	40
3.2. ISOBUS Wiring Harness	40
3.3. ISOBUS Ready Wiring Harness	40

3.4. ISOBUS Ready Pro Wiring Harness	41
4. Declaration of CE.....	42



1. Product Introduction

1.1. Overview

ISOBUS is a CAN-based communication protocol, also known as ISO 11783, an international, universal, and standardized communication protocol developed by the Agricultural Industry Electronics Foundation (AEF) for agricultural and forestry equipment. ISOBUS defines an equal protocol for all manufacturers of agricultural and forestry equipment to guarantee full compatibility between tractors, implements, and navigation equipment of all brands and models that are ISOBUS certified.

FJD ISOBUS is an advanced feature launched by FJDynamics with the following advantages:


1. Uniform standard. Enables the easy connection between FJD autosteering systems and ISOBUS certified implements from different brands.
2. Simplified device. Displays information and issues control instructions efficiently with no additional monitoring devices and cables except for those from FJD ISOBUS module.
3. Reduced cost and improved efficiency. Automatically controls the implement based on task planning, reducing labor cost and material consumption, and improving work efficiency and quality.
4. Precision agriculture. Creates favorable conditions for crop growth at all stages according to the growth model, and provides system diagnosis, optimized prescription, and scientific management.

The hardware of FJD ISOBUS function complies with the physical attributes of plugs and cables, network data formats, and interfaces defined in ISO 11783.

The software of the feature is embedded in the APP of FJD Auto Steer system, and will be upgraded and maintained along with it.

1.2. Main Components

1.2.1. ISOBUS Wiring Harness




CAN Box



TBC Box



ISOBUS Box




AT2 auxiliary wiring harness

1.

Main components

No.	Name	Purpose
1	CAN Box	Used to converts signals, with one end connected to the serial port of the control terminal of the FJD Auto Steer system and the other end connected to the TBC Box.
2	TBC Box	Biases and terminates the bus when the implement ECU is disconnected. It connects the CAN Box and the ISOBUS Box.
3	ISOBUS Box	Communicates with and powers the implement ECU through an international standard 9-pin connector.
4	AT2 auxiliary wiring harness	To connect the implement to the AT2 control terminal, connect the 12-pin connector of the CAN Box to the 12-pin connector of the AT2 auxiliary wiring harness.

1.2.2. ISOBUS Ready Wiring Harness



CAN Box



ISOBUS in-cab Cable



AT2 auxiliary wiring harness

2.

Main components

No.	Name	Purpose
1	CAN Box	Used to converts signals, with one end connected to the serial port of the control terminal of the FJD Auto Steer system and the other end connected to the ISOBUS in-cab Cable.



2	ISOBUS in-cab Cable	Used to connect the CAN Box and the in-cab connector that is already embedded in a tractor cab or other components such as auxiliary inputs and ISOBUS ECUs.
3	AT2 auxiliary wiring harness	To connect the implement to the AT2 control terminal, connect the 12-pin connector of the CAN Box to the 12-pin connector of the AT2 auxiliary wiring harness.


1.3. Hardware Installation

1.3.1. FJDynamics Auto Steer Kit




Refer to the *FJDynamics Auto Steer Kit Installation Instruction*.

1.3.2. ISOBUS Wiring Harness



- 1.Power off the FJD Auto Steer system and the tractor battery before connecting the ISOBUS wiring harnesses.
- 2.Fix the ISOBUS wiring harnesses in place. Do not twist or hang them in the air.
- 3.Connect the power port ⑤ of the ISOBUS Box wiring harness to the battery of the tractor. Do not turn the battery on until all wiring harnesses are properly connected.
- 4.Connect the implement ECU to the ISOBUS implement connector ④ of the ISOBUS Box wiring harness.
- 5.Connect the TBC Box wiring harness, the ISOBUS Box wiring harness, and the CAN Box wiring harness together.
- 6.Connect the 12-pin connector (female) ① of the CAN Box wiring harness to the same 12-pin connector (male) from the terminal of AT1 or the auxiliary wiring harness of AT2.
- 7.Turn on the battery and the main power switch for wiring harnesses to power on the FJD Auto Steer System.

1.3.3. ISOBUS Ready Wiring Harness



- 1.Power off the FJD Auto Steer system and the tractor battery before connecting the ISOBUS wiring harnesses.
- 2.Fix the ISOBUS ready wiring harnesses in place. Do not twist or hang them in the air.
- 3.Connect the in-cab connector ③ of the ISOBUS in-cab cable to the same connector in the tractor cab.
- 4.Connect the CAN Box wiring harness and the ISOBUS in-cab cable together.
- 5.Connect the 12-pin connector (female) ① of the CAN Box wiring harness to the same 12-pin connector (male) from the terminal of AT1 or the auxiliary wiring harness of AT2.
- 6.Turn on the battery and the main power switch for wiring harnesses to power on the FJD Auto



Steer System.

2. Software Operation Instructions

2.1. Overview of Operation Processes

This chapter introduces the FJD ISOBUS feature from a new user's perspective.



For autosteering-related features, refer to the *FJDynamics Auto Steer System Software User Manual*.

Operation procedure for using the ISOBUS feature of the system:

Installation and commissioning of FJDynamics Auto Steer System → Installation of ISOBUS wiring harnesses → Enable ISOBUS function → Load object pool → Setup an ISOBUS implement → Set the material → Set the task → Set the speed source → Start operation

2.2. Setting the Auto Steer System

The installation and commissioning process of FJDynamics Auto Steer Kit is as follows.

Select a language → Sign up and log in → Enter the installation information → Connect to RTK → Obtain heading* → Set the vehicle parameters → Calibrate the angle sensor → Calibrate the vehicle → Calibrate the implement → Complete

* Drive the vehicle straight ahead for a while, and the heading is obtained automatically. If not, choose **MENU > SYSTEM > Heading calibration**.




Refer to the *FJDynamics Auto Steer System Software User Manual* for details.

2.3. Function Enabling

Select **MENU > APPLICATIONS > ISOBUS** and enable the ISOBUS functions.



Note: Features such as the FJD Spray System, External Bluetooth RTK, and external radio cannot be used together with ISOBUS.




3.

Enable ISOBUS functions

2.3.1. Enable VT

VT is a free feature. Turn on VT in the ISOBUS module and the VT window is shown on the main interface.




4.

Enable VT

2.3.2. Activate and Enable TC-SC

Activation codes are needed to activate TC-SC, TC-GEO and AUX-N. To have a try-out of these functions, please turn to your dealer or FAE for help, they will apply for you. Enter the code in the pop-up window and check the activation information. Please remember that once the code is used, you may not activate the same function on another control terminal.

Turn on TC-SC in the ISOBUS module and the TC window is shown on the main interface.




5.

Enable TC-SC



2.3.3. Activate and Enable TC-GEO


TC-GEO shall be activated with the same procedure as TC-SC. Turn on TC-GEO, the entrance for configuring the prescription map and a "Rx" button for applying variable rate will be displayed in the TC window.



6. Enable TC-GEO

2.3.4. Activate and Enable AUX-N

AUX-N shall be activated with the same procedure as TC-SC. Turn on AUX-N and the "AUX" entrance for configuring auxiliary assignments will be displayed in the VT window.




7. Enable AUX-N

2.4. Implement Connection

Once the implement is properly installed and connected to FJD Auto Steer System, loading of VT and TC object pools will start instantly and you may check the loading progress in VT and TC windows.


Once the implement VT is connected, a tab with the VT address is displayed in the VT window on the left side. A description of the implement and its function is shown on the main interface in the VT window, followed by a main process bar, indicating the overall loading process. Another process bar shows the loading progress of each object pool from the VT. When the main process bar reaches 100%, the VT interface of the implement will appear in the VT window.



8.

VT object pool loading

TC object pool loading process is shown by a process bar in the TC window. When it reaches 100%, a pop-up window with the basic information of the implement will appear. Since it may take longer for the VT object pool to be loaded for the first time, when the pop-up window appears, it means TC is loaded while VT may still remain in the loading process.



9.

TC object pool loading




2.5. Preparation

2.5.1. Implement Setup

For each ISOBUS ECU, an ISOBUS implement needs to be created in Implement Library, and it will be the only implement bound up with the ISOBUS ECU. The next time when the ISOBUS implement is connected, the corresponding implement will be applied automatically.

Please follow the procedure below to create a new ISOBUS implement in **MENU > DEVICE SETTINGS > Implement Library**.



Procedure	Interface
<h3>Control Type</h3> <p>To create an ISOBUS implement, please select ISOBUS as the control type of the implement. The name of the implement ECU will be displayed underneath. There might be multiple choices if there is more than one ISOBUS device connected via CANBUS. Select the one that shares the same designator as your implement ECU and continue.</p>	
<h3>Type</h3> <p>The type of implement is chosen automatically if it is reported by the implement ECU. You may also edit it manually if it is not properly set.</p> <p>Press the "refresh" button in the bottom left corner, the chosen type will be refreshed to what is reported by the implement.</p>	
<h3>Information</h3> <p>The name and way of connection is set automatically if they are reported by the implement ECU. You may also edit them manually if they are not properly set.</p> <p>Press the "refresh" button in the bottom left corner, the name and way of connection will be refreshed to what is reported by the implement.</p>	

Parameters

- Skip/Overlap:** The spacing or overlapping between two adjacent rows.
- Implement working width:** Total width of the implement sections will be automatically calculated and filled in. It cannot be edited manually for ISOBUS implements.
- Implement overall width:** The total width of the implement. It is used to reserve the safety distance during automatic path planning and should be edited manually.
- Distance between hitch point to working point of implement:** The value is automatically calculated and filled in. It can be edited to better fit in the real working scenario.
- Distance between hitch point to rear of implement:** The total length of the implement. It is used to reserve the safety distance during automatic path planning.
- Implement offset:** The value is automatically calculated and filled in. It can be edited to better fit in the real working scenario.

Skip/Overlap: 0.000 m
Implement working width: 0.000 m
Implement overall width: 3.000 m

Distance between hitch point to rear of implement: 0.000 m
Implement offset: Right, 0.0 cm

Summary

Basic information of an implement is summarized on this page.

Press "Next" button to continue setting up the parameters, especially required by ISOBUS implements.

Name	Precision Spraying1	Way of connection	Three-point hitch
Brand of the implement			
Type of implement	Spraying		

Parameter	Value
Skip/Overlap	0.000m
Implement working width	0.000m
Implement overall width	3.000m
Distance between hitch point to working point of implement	0.000m

Channel

Each channel stands for a specific application scenario or a cultural practice.

Press the "refresh" button in the bottom left corner, some of the channel information will be refreshed all together to what is reported by the implement.

*Only one channel is supported at present.

Channel name	Type	Set state	Operation
Default	Spraying	Set	



Channel - Type

Enter the channel name and select a material for the channel.

When the type selected in the basic information of the machine is "tillage", "harvesting", "ditching", "leveling", or "ridging", the material configuration entrance of the channel "type" interface is hidden.

Enter target speed, minimum working speed and choose whether to work when back.

In the automatic section control mode, all sections are automatically closed when its speed is below the minimum working speed. It also stops working when reversing, if the "Stop Work When Reversing" setting is enabled. After the switch is enabled,

Channel - Offsets

If the working units of the implement channel are not mounted on the center of the boom, there will be an offset of the channel.

The offset of the channel is automatically synchronized from the implement ECU and can be edited too.

Channel - Latency

It may take some time for the sections to respond to the instructions, thus the instructions will be issued ahead of time to deal with the delay.

The latency of the channel is automatically synchronized from the implement ECU. However, if the implement fails to report the relevant parameters or does not support relevant settings, the required latency time can



Channel - Overlap

To avoid waste of material and pollution, sections will be automatically closed when they are out of boundary or inside the worked area. The performance of overlapping control will be defined by the parameters on this page.

*Refer to the chapter "Overlapping settings" for details.

Edit channel

Overlap

Boundary Switching Overlap	50 %	Coverage Switching Overlap	50 %
Boundary Start Overlap (a)	0.00 m	Coverage Start Overlap (a)	0.00 m
Boundary End Overlap (b)	0.00 m	Coverage End Overlap (b)	0.00 m

Back **Next**

Channel - Geometry

Number of sections and the width of each section will be automatically synchronized from the implement ECU. The total width of all sections is automatically calculated and displayed above.

Choose whether to enable section offset. All the offsets will not be applied to sections if this function is enabled. Off by default.

*If the section width is not synchronized properly (the value is 0 in a few cases), it can

SEEDING CHANNEL 1

Geometry

21.000m						Enable section offset	ON				
Section 1	Section 2	Section 3	Section 4	Section 5	Section 6	Width: 4.500m	Width: 4.500m	Width: 4.500m	Width: 4.500m	Width: 4.500m	Width: 4.500m
Front offset: 2.222m	L/R offset: 2.222m	L/R offset: 2.222m	L/R offset: 2.222m	L/R offset: 2.222m	L/R offset: 2.222m	L/R offset: 2.222m					

Last **Next**

Channel - Overview

Summary of channel information.

Edit channel

Type

Channel name	Default	Preferred in use	NO
Material Name	water		

Latency

Boundary latency-ON	500.0	Boundary latency-OFF	500.0
Application latency-ON	500.0	Application latency-OFF	500.0

Control information

Back **Save**

Overview

Summary of information of all channels.

Configuration

Implement control

Implement information

Name	Precision Spraying1	Type	Spraying
Vehicle Brand		SN	P20250811151400481501

Channel I

Channel name	Default	Prioritized	NO
Material Name	water	Control type	ISOBUS Task Control
Boundary latency-ON	500.0	Boundary latency-OFF	500.0

Back **Save**




Refer to the *FJDynamics Auto Steer System Software User Manual* for details of implement settings.



2.5.2. TC Object Pool Update

It can be noticed from the last chapter that some of the parameters of the implement are synchronized directly from the implement ECU, for example the section width. If these parameters do not meet the working scenario, they can be edited in VT following the implement use manual. The implement ECU might update its TC object pool when these parameters are edited in VT. The task will be paused until the new TC object pool finishes the transition.



10.

TC object pool update

2.5.3. Material Setup

A material carries critical information of target rates. To set up a new material or edit an existing material, select **MENU** > **DEVICE SETTINGS** > **Material Library**, tab **New** or **Edit** and fill in all necessary parameters.

New material

Material Name:

Material Type:

Target Rate I:

Rate Increment:

Material Code/ID:

Density:

Material Category:

Unit:

Target Rate II:

Rate Range: -

Material Brand:

Material library

Enter material name:

Default material

Material Configuration

Material Type	Herbicide
Material Name	herbicide
Material Category	Liquid Spraying
Material Brand	
Material Code/ID	
Unit	L/ha
Density	1.0
Target Rate I	100.0
Target Rate II	200.0
Rate Increment	10.0
Rate Range	80.0-300.0

11.

Material setup

Material Name	Enter the name of the material.
Material Category	Select the category of the material.
Material Type	Select the type of the material.


Unit	Select the unit for the material.
Target Rate I	Set the amount of materials intended to be applied.
Target Rate II	Optional target rate for fast switch during operation.
Rate Increment	Change in target rate with each adjustment.
Rate Range	Adjustable range of target rate.
Material ID	Enter the material ID.
Brand	Enter the brand of the material.
Density	For liquid material, enter the density from 0.8 to 1.2.

2.5.4. Import Task Files

Tasks created on FMS platform or other control terminals can be imported in the form of a standard TASKDATA.XML file via **Data Transfer**.

Enter the **Data Transfer** interface, select a TASKDATA.XML file or a folder that contains a TASKDATA.XML (which may also contain some external files that end with .xml). Click on the "Import" button and the task file will be imported and parsed. Please check the details of the imported task in **MENU > FIELD > Field**.

If the imported TASKDATA.XML does not contain information of Field, you have to select an existing field (you may also create a new field) to which the imported task belongs.



12.

Import task files

Note:

1. The imported task file should be named exactly as "TASKDATA.XML" (all capitalized).
2. When switching Field, Boundary, Guidance line or Task when there is an ongoing task, the task will be paused and can only be started manually after switching.


2.5.5. Task Setup

For quick setup of a new task, please go to **Overview** and complete the configuration of Field, Guidance line, Boundary, and Task. The implement will be automatically configured once the



implement ECU is connected.

Note: Only the tasks that fall under the group of "Incomplete" can be applied.



13.


Task setup

2.5.6. Prescription Setup

Please prepare a prescription map in advance. Prescription maps in XML, SHP and TIF format from the Farm Management System or other third-party platforms are supported. Please note the following requirements when generating the prescription file.

XML(offline)	Import the XML file together with the bin file, or you may also import a zip file that contains the XML and bin file.
XML(online_FMS)	Online transmission of XML prescription map is supported with the Farm Management System. Choose synchronize data and the prescription map will be synchronized to the bonded terminal. Check the imported prescription map in MENU > FIELD > Field > FMS field > FMS task > Prescription .
SHP	For prescription maps in SHP format, please add " prescription " (case insensitive) into the name of each file, otherwise they might be parsed as boundaries.
TIF	It may take some time (up to several minutes, depending on the file size) to import a TIF file, please wait patiently. Check the imported prescription map in MENU > FIELD > Field > current field > current task > Prescription .

Import the prescription map via Data Transfer or via online data transfer from FMS. Once imported successfully, the prescription map will be classified into **Menu > FIELD > Field > Prescription**.




14.

Prescription map

2.5.7. Check Record Mode

Once an ISOBUS implement is applied, the system will automatically enable the "Auto record-Section" mode, with which the record status of the worked area is determined by the ON/OFF status of each implement section. The record and rendering is started automatically when a section is ON.

Note: Other record modes may also be applied but the record of worked area and rendering of track will be less precise.






15. Recode mode

Manual record	The record status is consistent with the task status. The record starts when the task status is switched to "Work".
Auto record-Autosteering	When the task is ongoing, the record status is consistent with the status of driving mode. The record starts when in autopilot mode.
Auto record-Section	When the task is ongoing, the record status is consistent with the status of implement sections. The record starts when the implement sections are on. *Only available with ISOBUS implements
Auto record-Rate	When the task is ongoing, the record status is consistent with the status of implement sections and the real-time applied rate. The record starts when the implement sections are on and the applied rate is not 0. *Only available with ISOBUS implements when a prescription map is in use
Auto record-Lift sensor	When the task is ongoing, the record status is consistent with the position of implement according to the lift sensor. The record starts when the implement is lowered. *Only available when the lift sensor is connected and activated.
Auto record-Acre Recording Sensor	When the task is ongoing, the record status is consistent with the position of implement according to the Arce Recording Sensor. The record starts when the implement is lowered. *Only available when the Arce Recording Sensor is connected.

2.5.8. Speed source setup

Speed source should be configured before starting the operation, otherwise TC might not function properly. Ensure that the selected speed source is the same as what is set in the implement VT. The frequency must meet the communication requirements of the implement.

Note: Different implement manufacturers may require different frequencies. Confirm the frequency with the implement dealer if necessary.




16.

Speed source

2.6. Start Operation

2.6.1. Main Screen Elements

2.6.1.1 VT Window



17.


VT window

No.	Element	Description
①	VT window	Implement VT screen, consisting of the following elements.
②	VT tab	Tab to switch between and activate VTs.
③	Settings	Quick entry to ISOBUS settings.
④	Data mask area	Display the implement status, information, and alarm messages.



⑤	Softkey area	Screen buttons that allow for quick implement control.
⑥	ACK	Button to clear alarm pop-ups in VT.
⑦	AUX	Entrance to the assignment of auxiliary inputs and functions.
⑧	Zoom button	Button to zoom in and out of the VT window.

2.6.1.2 TC Window




18. TC window

No.	Element	Description
①	TC window	Implement TC screen, consisting of the following elements.
②	Rate info	Display the value of issued target rate from the terminal and actual rate reported by the implement.
③	Manual/Auto mode	Button to switch between manual and auto section control mode.
④	Section control	Group of elements related to section control.
⑤	Section status	Display the status of each section (yellow-on, gray-off, forbidden sign-disabled).
⑥	All sections ON/OFF	Turn on/off all sections with one click under manual mode.
⑦	Overlap control	Quick entry to edit overlap settings.
⑧	Rate control	Group of elements related to rate control.
⑨	Target & Rx rate switch	Allow for target rate adjustment and quick switch between target rate and prescription rate (Rx button).
⑩	Prescription rate control	Quick entry to configure a prescription map for the current channel.

⑪	Headland section control	Allow to choose headland section control mode during the usage of headland baseline. The entry is hidden when applying other baselines.
---	---------------------------------	---

2.6.2. Start/Pause Task

Click on the Record button in the Menu Bar to start a task. Please note when the task is paused, VT is still operable while TC may not function properly. Only when the task is started, does the system start to record the worked area.



19. Record button

2.6.3. VT Operation

The control terminal of the implement is taken over and displayed in the VT window. Checking running status of the implement and changing implement settings are supported, as if using the original implement control terminal.

*When enabled together with TC, VT is minimized under the default layout. You may click on the VT button on the top left of the VT window to maximize it.



20. Implement VT

2.6.4. TC Operation

2.6.4.1 Section control (TC-SC)

Sections will be turned on and off automatically under auto mode when passing the selected boundary and the worked area, in accordance with the settings of overlap. Sections can also be turned on and off manually under manual mode to better satisfy special control demand.



21.

Section control

Overlap settings for other materials	Interface
<p>Boundary Switching Overlap</p> <p>1%: Sections will be turned on until they completely enter the field boundary.</p> <p>50%: Sections will be turned on when half of them enter the field boundary.</p> <p>99%: Sections will be turned on once a tiny part of them just enters the field boundary.</p>	
<p>Boundary Start Overlap (a)</p> <p>Sections will be turned on <i>a</i> meters before it enters the field boundary.</p>	
<p>Boundary End Overlap (b)</p> <p>Sections will not be turned off until <i>b</i> meters after it leaves the field boundary.</p>	

Coverage Switching Overlap

1%: Sections will be turned off once a tiny part of them just enters the worked area.

50%: Sections will be turned off when half of them enter the worked area.

99%: Sections will be turned off until they completely enter the worked area.




Coverage Start Overlap (a)

Sections will be turned on **a** meters before it leaves the worked area when setted positive, turned on **a** meters after when the value the negative.

Coverage End Overlap (b)

Sections will not be turned off until **b** meters after it enters the worked area.



Special section control strategy

Interface


Section disabling

If some of the sections are not expected to be on under any circumstance, click on them under auto mode, they will be turned off and marked with a forbidden sign. Then the disabled sections will be kept off until they are released by another click.



Switching mode

When switching from auto section control mode to manual mode, all sections will be turned on except for disabled ones.






All Sections ON/OFF

With one click of the All Sections ON/OFF button, all sections will be turned on if there are some sections that are off, and all sections will be turned off if they are all on.



When applying the headland baseline, a new headland segment control setting entry is added to the TC window.(the entry is hidden when applying other baselines).




22.

Headland

Inner Field	Open sections only within the headland inner boundary, and automatically close sections in the headland area at the edge of the field. This mode is used by default.
Headlands	Open sections only within the headland area, and automatically close sections after entering the headland inner boundary.
All Field	Open sections in both the headland area and the headland inner boundary.

2.6.4.2 Rate control

Once material is configured, the implement will follow the target rate set with the selected material. Two target rates can be switched between by tabbing on the rate number. Target rate can be adjusted by pressing the "+" and "-" button during operation. The adjustment step is determined by "Rate increment" and adjustment range by "Rate range".




23.

Rate control

2.6.4.3 Variable rate control (TC-GEO)


Click on the button and select a prescription map for the current channel. Configure the necessary parameters such as default rate and latency. When there is a prescription map selected, it can be applied by tabbing on the Rx button. If the implement does not support TC-GEO, the entry button is grayed out. The legend above/below the navigation map indicates the relationship between the rate and the rendering color.

Click on the prescription display button , which has been added to the function sidebar on the right side of the main interface. The prescription map will be presented on the navigation interface with 30% transparency.



24.

Variable rate control



25.


Prescription map configuration

Default rate	Rx rate will be replaced by default rate if it configued for "When Leaving Treatment Zone".
min & max	The minimum and maximum value out of all treatment zones.
ON/OFF Latency	Control signals will be issued ahead of time to deal with the delay of the implement's rate controller.
When Leaving Treatment Zone	The rate control strategy when leaving treatment zones.
Rendering Color	Each rendered color corresponds to 8 color numbers. The color scheme set here will be applied to the prescription map display.

2.6.5. Auxiliary control (AUX-N)

If the implement supports AUX-N and there is also a joystick/switch panel connected, then the AUX button will be highlighted, showing that the auxiliary assignment is supported.


The ISOBUS joystick or switch panel will also provide a VT that demonstrates its configuration state.



26.

VT of joystick

Tab on the AUX button and assign the required auxiliary function from the implement to an auxiliary input from the joystick/switch panel in the pop-up window. Turn to Learn mode and press the physical button on the joystick/switch will also complete the assignment without having to select an input button from a pull-down list. After assigning joystick (or other auxiliary devices) buttons to implement functions, joystick can be used to control the implement directly.




27.

Auxiliary assignment window

2.7. ISOBUS Module

ISOBUS Module provides the buttons to activate and enable the ISOBUS sub-functions. Basic information of the implement ECU and the operating parameters is displayed at the top right. The main interface of the ISOBUS module also provides three other entrances, which are described in details below.




28.

ISOBUS module

2.7.1. Implement Info

The Info sector is split into two parts. The left column contains VT information, such as the loading progress, object pool file and supported language of each VT. The right column shows the implement bound with implement TC and the material used for the channel. When the implement channel is not configured with materials, only the implement channel name is displayed, and the material information is not displayed. The arrow on the right is provided to quickly jump to the material library to switch to other materials.



29.

Implement info

2.7.2. Statistics

Statistics of the current task such as operation time and operation area can be checked in the Statistics sector.

You may check the statistics of the current task here. If the implement doesn't report task totals, the relative data will go blank.

Statistics

ISOBUS-Sprayer
FJD ATS-C Precision Sprayer

Task Totals			
Start time	Last update		
2025-03-19 15:11:00	2025-03-19 15:27:59		
Operation Hour	Effective Distance		
5.000	s	21.550	m
Total Area	Total Application		
0.03	ha	0	L

30.

Statistics

2.7.3. Settings

ISOBUS related settings are displayed in the Settings sector. There is also a quick entry to these settings in the VT window, below all the VT tabs.



Communication Module

DTU SN: DTU BOM ID: DTU FIRMWARE:

Object pool management

8354200b008008a0161015Pdat 0e0c0ad00800ca06248BF0.dat

Manufacturer Code

1390

Connection Timeout

6 s

CTS

OFF

Language English(en)

Speed source

GPS Position: 1Hz OFF GPS J1939: 1Hz OFF

ISO 11783 Wheel: 1Hz ON ISO 11783 Radar: 1Hz OFF

Alarm Notification

OFF

VT Number

1

ISB

ON

Monitor implement status

OFF

Verify VT object pool


OFF

31.

Settings


Elements	Description
Communication Module	Reporting of version information is supported by new DTUs with firmware version 2.2.0.0 and above.
Object pool management	Please be careful when deleting the VT object pool that is currently in use. Once deleting it, you need to wait for the VT object to be loaded next time you turn on the system.
Manufacturer Code	1390 is the manufacturer code of FJDynamics. Please do not change it unless instructed by the dealers or service people.

Connection Timeout	If the heartbeat signal of the implement is not detected for a while, it is seen as disconnected. Please do not change it unless instructed by the dealers or service people.
CTS	Retransfer will be attempted when VT object pool transfer is interrupted by CTS mechanism.
Language	All language options supported by connected VTs are presented in the pull-down list. Select the intended language and it will take effect on all connected VTs. If the implement ECU does not support the selected language, the language setting will not take effect.
Speed source	Refer to the chapter "Speed source setup".
Alarm Notification	Once enabled, the terminal will produce an alarm sound when there is an alarm mask in VT.
VT Number	VT number is recommended to be set to 1. Please do not change it unless instructed by the dealers or service people.
ISB	When the function is enabled, an ISB button is displayed on the VT window. Tapping the button will send an ISB signal to the implement, causing it to freeze and stop working immediately. *It is useful only when the implement is capable of ISB function.
Monitor Implement statuses	When the function is enabled, the work status of the implement will be received by the terminal. Sections turn on/off automatically according to the real status of the implement. *It is useful only when the implement are able to send its status via DDI 141 through ISOBUS wire.
Verify VT Object Pool	When the switch is off, no object pool compliance check is performed. Object pools that do not comply with the ISOBUS standard may be loaded, which may affect system stability.



32.

VT number verification



33.

ISB function

3. Hardware Specifications

3.1. FJDynamics Auto Steer Kit

For details, see "Main Hardware and its Specifications" of the *FJDynamics Auto Steer Kit Software User Manual*.

3.2. ISOBUS Wiring Harness

Component	Specifications
ISOBUS Wiring Harness	<p>Operating voltage: 9-36 V</p> <p>Communication protocol: CAN</p> <p>CAN baud rate: 250 Kbps</p> <p>Operating temperature: -30°C to 70°C</p> <p>Operating humidity: 5% to 95%</p> <p>Storage temperature: -45°C to 85°C</p> <p>IP rating: IP66</p>

3.3. ISOBUS Ready Wiring Harness

Component	Specifications
ISOBUS Ready Wiring Harness	<p>Operating voltage: 9-36 V</p> <p>Communication protocol: CAN</p> <p>CAN baud rate: 250 Kbps</p> <p>Operating temperature: -20°C to 70°C (ISOBUS in-cab Cable needs to be placed in the tractor cab)</p> <p>Operating humidity: 5% to 95%</p> <p>Storage temperature: -45°C to 85°C</p> <p>IP rating: IP66</p>



3.4. ISOBUS Ready Pro Wiring Harness

Component	Specifications
ISOBUS Ready Pro Wiring Harness	<p>Operating voltage: 9-36 V</p> <p>Communication protocol: CAN</p> <p>CAN baud rate: 250 Kbps</p> <p>Supports Bluetooth,WiFi</p> <p>Operating temperature: -20°C to 70°C (ISOBUS in-cab Cable needs to be placed in the tractor cab)</p> <p>Operating humidity: 5% to 95%</p> <p>Storage temperature: -45°C to 85°C</p> <p>IP rating: IP66</p>

4. Declaration of CE

Declaration of Conformity Hereby, FJ Dynamics Technology Academy (Changzhou) Co., Ltd. Shenzhen Branch declares that the radio equipment type WIFICAN/ISORDY-Pro is in compliance with directive 2014/53/EU.



The full text of the EU declaration of conformity is available at the following internet address:<https://fjdynamics.feishu.cn/file/JDkQb8WujoW70kxWtVXcEzOmn9g>

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of $d=20$ cm between the device and the human body. To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device and human body.

Frequency bands and power

	Bands	Operation Frequency	Max.Power
Bluetooth	2.4GHz	2402-2480 MHz	EIRP 7.01dBm
Wi-Fi	2.4GHz	2412-2472MHz	EIRP 18.46 dBm

This product can be used across EU member states.

Do not use the device in the environment at too high or too low temperature, never expose the device under strong sunshine or too wet environment.

The suitable temperature for the product and accessories is -20°C to 60°C



© 2025 FJDynamics. All rights reserved.